

Choose your plan

To make things simple, we have listed the main features of the two plans available: **Standard & Pro**. If you choose **Standard** now, you can always upgrade to **Pro** later, as your needs change.

For further information on how any of these features work or might benefit you, contact our Tele-Gence team (see details at the bottom).

		Standard	Pro
Alerts	Real time alerts via platform, email or SMS such as impact alerts and out of hours movement	✓	✓
Fuel card integration	MPG and CO2 reports Fuel fraud notifications	✓ ✓	✓ ✓
Reports	Customisable reports scheduled to your inbox including timesheets and mileage reports	✓	✓
Support	Dedicated UK-based support team and user guides available online	✓	✓
Tracking	Updates every 10 seconds Smartphone enabled Roaming SIMs and worldwide coverage	✓ ✓ ✓	✓ ✓ ✓
User roles	Unlimited administrator roles with the ability to customise each user's access	✓	✓
Dashboard	Analyse your fleet data including: driver performance league table and fuel trends across different cost centres and asset groups	✗	✓
Driver behaviour	Tailor driver behaviour scores to determine your best and worst drivers Monitor dangerous speeding with Overspeed Profiles and set maximum speed restrictions for vehicles compared to road speed	✗ ✗	✓ ✓
Traffic visibility	Multiple map layers such as real-time traffic, street, hybrid and satellite view	✗	✓
Zones	Report and alert on activity within unique gee-fence (polygonal) zones	✗	✓

For further information contact info@tele-gence.co.uk
Visit our website www.tele-gence.com